
Olecranon Hook Plate[™]


Elbow & Forearm System






Exposure and Reduction

- Expose the olecranon with a standard posterior approach.
- Reduce the fracture and hold with K-wire(s).
- Make two longitudinal incisions in line with the fibers of the triceps insertion down to the proximal tip of the olecranon.




Guide Preparation

• Apply the Hook Drill Guide to the olecranon ensuring the guide is completely seated and flush with the bone. Drill two holes through the outer cortex with a 2.3mm (red) drill.




Hook Plate Insertion

- Insert the plate's hooks into the holes drilled in the olecranon.
- Seat the Impactor between the two hooks and impact the plate into the distal fragment.
- Confirm that the reduction is adequate.
- Place a non-locking 3.2mm cortical screw in the end of the slotted hole that is farthest from the fracture.




Expander/Compression Tool

- Insert screwdriver tip of the Expander/Compression Tool into screw head and engage jaw into the adjacent screw hole away from the fracture or osteotomy.
- Loosen screw 1/4 turn.
- Gently sqeeze the Expander/Compression Tool to obtain the desired compression. Tighten screw.



Final Fixation

• Complete fixation with 3.2mm cortical screws, as needed.



CE 1639





The technique presented is one suggested surgical technique. The decision to use a specific implant and the surgical technique must be based on sound medical judgment by the surgeon that takes into consideration factors such as the circumstances and configuration of the injury.

This document is controlled by TriMed, Inc. When downloaded, printed, and/or copied, this document becomes uncontrolled, and users should always check trimedortho.com for the latest version.

For indications, contraindications, warnings and precautions related to TriMed Elbow & Forearm System reference IFU on trimedortho.com/ifu. See trimedortho.com/patents for all patent information.